


# "Hands-Free" Sanitizer Station

## Set-up Guide


**MADE IN THE USA**



Base Model/Metal Finish  
SANIO20-PLAIN



Standard Model  
SANIO20



Custom Model  
SANIO20-CUSTOM



# BOB'S SPACE RACERS

427 WHAC-A-MOLE WAY  
HOLLY HILL, FLORIDA 32117

1-386-677-0761

[SALES@BOBSSPACERACERS.COM](mailto:SALES@BOBSSPACERACERS.COM)

[WWW.BOBSSPACERACERS.COM](http://WWW.BOBSSPACERACERS.COM)

# "Hands-Free" Sanitizer Station

## What's Included:

- Pump Nozzle
- Back Panels

## Optional:

- One Gallon of Sanitizer (sold separately)



**Back Panel**



**Pump Nozzle**  
**PART#-M0005354**



**One Gallon of**  
**Sanitizer (optional)**  
**PART#-M0005350**  
**Sold Separately**

## Unpacking instructions:

1. Open box from the top.
2. Remove packing material from the top.
3. Pull unit up and out of box.
4. Remove foam from under nozzle cover.
5. Remove wood panel.
6. Unwrap back panels.

# "Hands-Free" Sanitizer Station



## Installing Sanitizer:

1. Insert pump nozzle into one gallon jug.
2. Prime pump by pressing down on nozzle until sanitizer solution comes out.
3. Press down on nozzle and slide bottle onto shelf.
4. Check that top of pump nozzle hits the bottom of top plate, if needed adjust lower rod assembly until properly set.
5. Insert back panel


## Removable tray:

Note: Unit includes front removable tray for easy clean-up.

Hand-Free Sanitizer Station has been set at the factory to provide approximately 4000-8000 pumps. If desired it can be adjusted to distribute more or less depending on amount of adjustment.

## Foot Pedal Adjustment:

1. For more, loosen hex nuts and lower hex bolts, then tighten hex nuts.
2. For less, loosen hex nuts and raise hex bolts then tighten hex nuts.
3. Note – small adjustments make a big difference in output of sanitizer solution.



For Parts - Call: 1-386-677-3803 or Email: [parts@bsrgames.com](mailto:parts@bsrgames.com)

